


INKBIRD

SMART HOME SMART LIFE



Thermometer and Hygrometer

Model:ITH-20



Please keep this manual properly for reference. You can also scan the QR code below to visit our official web site for product usage videos. For any usage issues, please feel free to contact us at **support@inkbird.com**.

Wenn Sie eine Bedienungsanleitung in deutscher Sprache benötigen, scannen Sie bitte den QR-Code und besuchen Sie unsere Website, um sie zu erhalten und ein Video über die Verwendung des Produkts zu sehen.

Se avete bisogno di un manuale di istruzioni in italiano, scansionate il codice QR e visitate il nostro sito web per ottenerlo e vedere un video su come utilizzare il prodotto.

Si vous avez besoin d'un mode d'emploi en français, veuillez scanner le code QR pour visiter notre site officiel afin d'obtenir et de visionner la vidéo d'utilisation du produit !

Als je een Nederlandstalige handleiding nodig hebt, scan dan de QR-code om naar onze officiële website te gaan en bekijk de video over het gebruik van het product!

Si necesita el manual de instrucciones en español, escanee el código QR para ir a nuestro sitio web oficial y ver el vídeo sobre cómo utilizar el producto.




Warm tips

- To quickly jump to a specific chapter page, click on the relevant text on the contents page.
- You can also use the thumbnail or document outline in the top left corner to quickly find a specific page.


01	Know the Thermometer and Hygrometer	1
02	Function Parameter	2
03	Button Icon Description	3
04	Degree of comfort	4
05	Troubleshooting Guide	4

1. Know the Thermometer and Hygrometer

● Front view




● Back view



2.Function Parameter

- Dimensions: 64mmx75mmx20mm
- Weight:47g
- Battery: 2xAAA Batteries
- Real-time temperature and humidity display, MAX/MIN displays on the same screen
- Temperature Measurement Range:
-10°C ~ 50°C (14°F ~ 122°F)
- Humidity Measurement Range: 10% ~ 99%
- Temperature Display Accuracy: 0.1°C (0.1°F)
- Temperature Measurement Accuracy: $\pm 1.0^{\circ}\text{C}$
- Humidity Measurement Accuracy: $\pm 5\%$
- Humidity Display Accuracy: 1%
- Temperature and humidity sampling period: 10 seconds
- Out of range display "HH.H" or "LL.L" ,sensor Error, display "-- --.--"
- LCD can be turned off
- Warranty: 1 year

3.Button Icon Description



CLEAR: Clear MAX/MIN Memory Value

C/F: Temperature Unit Switching

LCD ON/OFF: LCD ON/OFF

4.Degree of comfort

- (DRY): Relative humidity below 40% RH at any temperature
- (COMFORT): The temperature range is (20 ~ 30)°C
the relative humidity is (40 ~ 70)% RH
- (WET): Relative humidity above 70% RH at any temperature

5.Troubleshooting Guide

Issues	Causes	Solutions
Inaccurate temperature reading.	1. It is placed in a area with poor temperature circulation. 2. The probe port is blocked. 3. Device malfunction.	1. Adjust the position of the device. Leave it for a while so that the reading can stabilize. 2. Check whether the probe port is blocked.

Issues	Causes	Solutions
Inaccurate humidity reading.	1. Water or condensation enters the probe. 2. The probe port is blocked. 3. Device malfunction.	1. Adjust the position of the device. Leave it for a while so that the reading can stabilize. 2. Check whether the probe port is blocked.

Shenzhen Inkbird Technology Co.,Ltd.

support@inkbird.com

Consignor: Shenzhen Inkbird Technology Co., Ltd.

Office Address: Room 1803, Guowei Building, No.68 Guowei Road,
Xianhu Community, Liantang, Luohu District, Shenzhen, China

Manufacturer: Shenzhen Inkbird Technology Co., Ltd.

Factory Address: Room 501, Building 138, No. 71, Yiqing Road,
Xianhu Community, Liantang Street, Luohu District, Shenzhen, China

MADE IN CHINA

DESIGNED BY INKBIRD

V5.0