
# **INKBIRD**

RHT-11K





Please keep this manual properly for reference. You can also scan the QR code to visit our official website for product usage videos. For any usage issues, please feel free to contact us at **support@inkbird.com**.

Wenn Sie eine Bedienungsanleitung in deutscher Sprache benötigen, scannen Sie bitte den QR-Code und besuchen Sie unsere

Website, um sie zu erhalten und ein Video über die Verwendung des Produkts zu sehen. Se avete bisogno di un manuale di istruzioni in italiano, scansionate il codice QR e visitate il nostro sito web per ottenerlo e

vedere un video su come utilizzare il prodotto. Si vous avez besoin d'un mode d'emploi en français, veuillez scanner le code QR pour visiter notre site officiel afin d'obtenir et

de visionner la vidéo d'utilisation du produit!

Als je een Nederlandstalige handleiding nodig hebt, scan dan de QR-code om naar onze officiële website te gaan en bekijk de video over het gebruik van het product!

Si necesita el manual de instrucciones en español, escanee el código QR para ir a nuestro sitio web oficial y ver el vídeo sobre cómo utilizar el producto.



Warm tips

- To quickly jump to a specific chapter page, click on the relevant text on the contents page.
- You can also use the thumbnail or document outline in the top left corner to quickly find a specific page.

# **CONTENTS**

07 Technical Specifications	04 Battery Installation 05	07 Troubleshooting Guide
02 Product Diagram	05 Operation Instructions 06	08 FCC Requirement 09
03 Operating Buttons Definitions 04	06 Important Notes/Warnings 07	09 Customer Service


### 01 Technical Specifications


Brand	INKBIRD	Measurement Accura
Model	RHT-11K	Resolution of Display
Readout Time	0.5s	Resolution of Display
Measurement Mode	Immersion/Penetration	Product Usage
Temperature Measurement Range	-58.0°F~512°F/-50.0°C~300°C	Floudet Osage

Measurement Accuracy	±0.3°C/±0.5°F	
Resolution of Display	0.1℃/°F(<100℃/212°F), 1.0℃/°F(≥100℃/212°F)	
Product Usage	Measuring food, liquids, pastes and semi- solid materials	

Screen Type	LCD with backlight	Battery	2 AAA(1.5V) batteries
Screen Size	1.42inch*0.87inch/36MM*22MM	Waterproof Level	IPX5
Product Size	6.89inch*2.00inch*0.79inch/ 174.9mm*50.9mm*20mm	Packing List	Thermometer * 1, User manual * 1, AAA battery * 2,
Product Weight	4.16oz/118g		Cross-head screwdriver * 1


#### 02 Product Diagram






(HOLD) Short press to lock or unlock the temperature; in temperature calibration mode, press to decrease the parameter.

(0) When the probe is unfolded, press and hold for 3 seconds to switch the thermometer on or off.



Step 1:
Use a screwdriver to open the battery compartment.



Step 2:

Install the batteries correctly according to the polarity symbols in the battery compartment.

#### Step 3:

Use the screwdriver to tighten the battery compartment.

NOTE: Please use new AAA alkaline batteries. Do not mix old and new batteries or use rechargeable or standard (carbon-zinc) batteries.

#### Operation Instructions

Temperature Calibration

- 1. Unfold the probe, insert the probe into the center of the food and wait for the screen reading to be stable, this will give you the correct temperature. Short press the (HOLD) button to lock the currently detected temperature for easier viewing.
- 2. If the thermometer is left unused, it will automatically switch off after 10 minutes.
- 3. When the probe is unfolded and the backlight is dimmed, the backlight will automatically turn on if the probe detects a temperature change.
- 4. When the probe is unfolded, press and hold the (U) button for 3 seconds to switch the thermometer on or off, this saves power when cleaning the device.
- Press and hold the button for 3 seconds to display the character CA and enter the temperature calibration mode.
   Short press the button again to enter the setting of temperature calibration value, and press (the button again to enter the parameter.)
- If there is no operation, the thermometer will automatically save the set temperature calibration value in 10 seconds and exit the setting state.

#### 06 Important Notes/Warnings

Please clean and air-dry the probe after use.

- Do not force the probe apart. Rotate the probe to a position where it cannot continuously be rotated and stop.
- Please do not let the probe touch the fire, or it may result in burning and fusing.
  Please insert the probe deep enough into the meat if the display reading value is too high or increases too quickly. To detect the temperature of the meat, the probe
- should be inserted into the thickest part of the meat. Avoid bones and fat.

  Please wear gloves when you clean or use the probe. Do not touch the probe immediately after use, or it may result in scalding or stab wounds.
- Please wear gloves when you clean or use the probe. Do not touch the probe immediately after use, or it may result in scalding or stab wounds
   Please keep the probe away from children to avoid possible harm.
- Please do not immerse the thermometer in the water, though it can be rinsed with water.
- Please do not use the product beyond the temperature range from -50°C to 300°C (-58°F to 572°F), or it may cause damages.
- Please do not use the product beyond the temperature range from -50 C to 300 C (-58 F to 572 F), or it may cause damage.
   Children aged 12 or under 12 should use it with parental guidance.
  - )7

## 07 Troubleshooting Guide

Issues	Causes	Solutions
Probe reading is incorrect.	<ol> <li>The measurement time is too short.</li> <li>The probe is damaged.</li> </ol>	Extend the probe detection time to ensure stable readings.     Test the probe by measuring boiling water at 100°C (212°F) without touching the container.     If the deviation is small, please use the calibration function.
Can it be calibrated?	Yes. Calibration range is -5.0~5.0°F/-3.0~3.0°C	1. Press and hold the button for 3 seconds to display the character CA and enter the temperature calibration mode.  2. Short press the button again to enter the setting of temperature calibration value, and press or

Device not working	The AAA batteries are exhausted or damaged.     Check that the AAA batteries are installed correctly.	Replace with 2 new AAA batteries to ensure sufficient battery power.     Make sure the batteries are installed correctly according to the battery polarity.

#### 08 FCC Requirement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

The same of the sa

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

#### 09 Customer Service

This item carries a 2-year warranty against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of INKBIRD, be either repaired or replaced without charge. For any problems in use, please feel free to contact us at **support@inkbird.com**. We will do our best to help you.

# **Shenzhen Inkbird Technology Co., Ltd.**

Consignor: Shenzhen Inkbird Technology Co., Ltd.

Office Address: Room 1803, Guowei Building, No.68 Guowei Road, Xianhu Community, Liantang, Luohu District, Shenzhen, China

Manufacturer: Shenzhen Inkbird Technology Co., Ltd. Factory Address: 5th and 6th Floor, Building 138, No. 71, Yiqing Road, Xianhu Community, Liantang Street, Luohu District, Shenzhen, Guangdong, China





support@inkbird.com











DESIGNED BY INKBIRD